




LOWER OVEN PARTS

For Models: RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14

(Black) (Designer White) (Biscuit)

(S.Steel)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
STD-CLEAN LOWER
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS


For Models:RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14
(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			6	4450935	Plug, Door	37	4451354	Fuse—Thermal
LOWER OVEN PARTS			7	4455865	Top, Chassis		4449809	Screw
1	LIT4455993	Literature Parts Installation Instructions		4449809	Screw	43	4455530	Base, Chassis
	LIT8300772	Use & Care Guide (Oven)	9	4452159	Tube, Vent		4449154	Screw
	LIT8302068	Tech Sheet		4449154	Screw	49	4448933	Retainer, Gasket
	LIT3191638	Safer Cooking Tips	10	4451664	Fan & Bracket Assy.		4449154	Screw
2		Trim, Side		4454943	Plate, Fan	50	4451747	Cover, Back
	4450850	RH Black		4449809	Screw		4449809	Screw
	4450851	RH White	11	4452368	Oven Light Assy	51		Trim, Bottom
	4452122	RH Biscuit	12	4452166	Bulb, Light		4448477	Black Model
	4450853	LH Black	13	4452165	Lens, Light		4448478	White Model
	4450854	LH White	14	4455612	Frame, Front		4452415	Biscuit Model
	4452123	LH Biscuit		4449040	Screw		3400832	Screw
	8281236	Screw		4450118	Nut	53	4449845	Support, Bracket
3		Hinge Receiver	15	4450493	Gasket, Door		4449809	Screw
	4455605	Left Hand	19	4451478	Support, Insulation	FOLLOWING PARTS NOT ILLUSTRATED		
	4455606	Right Hand	25	4455641	Side, Chassis (R.H. & L.H.)			
4	4448520	Bumper, Door		4449809	Screw	INSULATION		
			26	4452234	Back, Chassis			
				4449809	Screw		4449316	Insulation, Wrap
			27		Liner, Oven (Not serviceable)		4450365	Insulation, Back
			29	4455636	Sensor			
				4449154	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14
(Black) (Designer White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models:RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14


(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			19	4451478	Support, Insulation	34	4452267	Vent, Center
				4449809	Screw	37	4451442	Thermostat (TOD)
			20	4451605	Cap, Spacer		4449809	Screw
			21		Rail, Side	49	4448933	Retainer, Gasket
3		Hinge, Receiver		4450581	Right Side		4449154	Screw
	4455605	Left Hand		4450582	Left Side	50	4451747	Cover, Back
	4455606	Right Hand		4448444	Grommet		4449809	Screw
4	4448520	Bumper, Door		4449154	Screw	53	4449845	Support, Bracket
7	4455865	Top, Chassis	22	8302157	Latch, Motorized		4449809	Screw
	4449809	Screw		4449809	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
9	4452158	Tube, Vent	25	4455641	Side, Chassis (R.H. & L.H.)	INSULATION		
	3196176	Screw		4449809	Screw		4449316	Insulation, Wrap
10	4452165	Lens, Light		4452234	Back, Chassis		4450365	Insulation, Back
11	4452368	Oven Light Assy	26	4449809	Screw			
12	4452166	Bulb, Light	27		Liner, Oven (Not serviceable)			
14	4455612	Frame, Front						
	4449040	Screw	29	4455636	Sensor			
	4450118	Nut		4449154	Screw			
15	4455382	Gasket, Door						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN DOOR PARTS

For Models:RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4455618	Door Liner
3	4449259	Glass, Inner
6		Hinge, Door
	8300565	R.Side (Lt. Brn)
	8300566	L.Side (Lt.Brn)
	8300567	R.Side (Red)
	8300568	L.Side (Red)
	3400832	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

12		Door Glass, Outer
	4452065	Black Model
	4452066	White Model
	4452859	Biscuit Model
	8300995	S.Steel Model
13		Door Handle
	4448854	Black Model
	4448855	White Model
	4452860	Biscuit Model


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

14	4450813	Bracket, Handle(2)
	4451040	Screw
	4449743	Screw (2)
20	8300778	Retainer, Glass
	4449809	Screw
21	8300820	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4452119	Biscuit Model
	4449743	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN DOOR PARTS

For Models: RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4455618	Door Liner
2		Hinge, Door
	8300571	R.Side (White)
	8300572	L.Side (White)
	8300573	R.Side (Lt.Blue)
	8300574	L.Side (Lt.Blue)
	3400832	Screw
3	4449259	Glass, Inner

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

4	4451722	Insulation, Door
7	4449263	Glass, Inner (2)
9	4450470	Retainer, Glass
	4449809	Screw
12		Door Glass, Outer
	4452065	Black Model
	4452066	White Model
	4452859	Biscuit Model
	8300995	S.Steel Model
13		Door Handle
	4448854	Black Model
	4448855	White Model
	4452860	Biscuit Model

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


14	4450813	Bracket, Handle
	4451040	Screw
	4449743	Screw (2)
19	4450362	Shield, Heat
	4449809	Screw
20	8300778	Retainer, Glass
	4449809	Screw
21	8300820	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4452119	Biscuit Model
	4449743	Screw
24	8300974	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models:RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14

(Black) (Designer White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	Control Panel Assy. W/Membrane Switch
	8300435 Black Model
	8300436 White Model
	8300533 Biscuit Model
	8281179 Screw
2	4451034 Gasket, Control Panel
3	8301917 Assy, Control
	4449745 Screw
	3400832 Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	4451759	Vent, Exhaust
	4449040	Screw
2	4455178	Elbow, Vent-Top
3	4455334	Blower, 60MM
	4455352	Bracket
	4449809	Screw
4	4455177	Elbow, Vent-Bottom

Illus. No.	Part No.	DESCRIPTION
5	8300642	Transformer, Control
11	4449868	Block, Terminal
	3400080	Screw
13	4448549	Vent, Control Panel
	4450038	Screw
14	4451597	Right Side, Control Top
	4451598	Left
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
15	4452244	Back, Control
	4449809	Screw
16	4450551	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp, Conduit
	4449809	Screw
18	4452367	Cover, Top Front
	4449809	Screw
21	4451758	Seal, Foam
22	8302143	Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RBD305PDB14, RBD305PDQ14, RBD305PDT14, RBD305PDS14

(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

4454835	Tie, Cable
4451761	Support, Wiring
4452222	Spacer-Harness
4449809	Screw
4454842	Tie, Cable
8302154	Harness, Wire (Main DOC)
4450953	Conduit, Double
4450800	Screw, Ground
4448664	Clamp
4449809	Screw
112432	Nut

Miscellaneous

814381	Pin Hinge Kit
814387	Roll Tape, Exhaust Duct
4448950	Screw, Install (4)